

# QUICK START GUIDE

## SETTING THE CLOCK

1. Press the CLOCK pad to start.
2. Use the number pads to enter the time of day.
3. Press the CLOCK pad to set.

## POPCORN

1. Press the POPCORN pad 1 time for a 3.5 ounce bag.
2. Press the POPCORN pad 2 times for a 3.0 ounce bag.
3. Press the POPCORN pad 3 times for a 1.75 ounce bag.
4. Press the START pad to start cooking.

**NOTE:** Press STOP pad when popping slows to 1-2 seconds between pops.

Overcooking will cause scorching and burning. Open bag carefully. Bag and contents are very hot. Children should not prepare without adult supervision.

If you are using a different size of bag than the above preset weights, please use the TIME COOK pad for manual time setting as instructed on the popcorn bag.

## EXPRESS COOK (AND REHEAT)

Press the numbers 1 to 6 for 1 to 6 minutes of instant cooking at 100% power.

**NOTE:** Numbers 7 to 9 are not programmed for EXPRESS COOK. Can only be used when setting "COOKING TIME".


## +30 SECONDS

1. Press the +30 SEC pad for 30 seconds of instant cooking at 100% power.
2. Repeatedly pressing the +30 SEC pad adds additional time.

## SETTING A COOKING TIME

1. Press TIME COOK pad.
2. Use the number pads to enter cooking time.
3. Press START pad to start cooking.

## HOW TO INSTALL GREASE FILTERS



To install the grease filter, slide the grease filter into the grease filter holder. Insert the grease filter holder into the designated area of the bottom of the oven.